

| Wall transmitter Format 55 |   | associated rockers |  | Switch ranges**   |
|----------------------------|---|--------------------|--|---|
|                            | + |                    |  | <b>BERKER</b> S.1, B.3, B.7<br><b>GIRA</b> Standard55, E2, Event, Esprit, ClassiX<br><b>JUNG</b> A500, AS 500, A Creation, Aplus<br><b>MERTEN</b> 1-M, Atelier-M, M-Smart, M-Pure, M-Pure Decor, M-Plan, M-Creativ<br><b>ELSO</b> JOY, with combination frame 55 RIVA, SCALA, FASHION<br><b>BUSCH-JAEGER</b> Balance<br>Color variations: (-xxP-)<br>02P - white<br>24P - anthracite<br>25P - lacquered aluminium |
|                            | + |                    |  |   |
|                            | + |                    |  |   |
| Wall transmitter Format B5 |   | associated rockers |  | Switch ranges**   |
|                            | + |                    |  | <b>Busch-Jaeger:</b><br>Reflex SI, Reflex SI Linear, Busch-Duro 2000 SI, Busch-Duro 2000 SI Linear<br>with spacer ring<br>carat, solo, Busch-axcent, future linear<br>Color variations: (-xxP-)<br>02P - white<br>07P - ivory white   |
|                            | + |                    |  |   |
|                            | + |                    |  |   |
| Wall transmitter Format B6 |   | associated rockers |  | Switch ranges**   |
|                            | + |                    |  | <b>Busch-Jaeger:</b><br>carat, solo, Busch-axcent, future linear<br>Color variations: (-xxP-)<br>02P - white<br>07P - ivory white   |
|                            | + |                    |  |   |
|                            | + |                    |  |   |

\*\* The names, terms and symbols may be protected brand names and trademarks belonging to their respective companies/legal owners.

| secwave - the radio system for access control |  |  |  |  |
|---|--|--|--|--|
|   |  |  |  |  |

Not compatible with Easywave products!

## PRODUCT RANGE















RADIO SYSTEMS: Flexibility | Convenience | Energy efficiency | Security



**TRANSMITTERS**

|   |   |   |  |   |   |   |   |   |   |   |   |
|---|---|---|--|---|---|---|---|---|---|---|---|
|  |  |  |  |  |  |  |  |  |  |  |  |
| RT21E5001-01-23K<br>Hand transmitter<br>1x PULSE                                  | RT21E5002-01-23K<br>Hand transmitter<br>2x PULSE                                  | RT30E5001-01-xxK*<br>1x UP/STOP/DOWN<br>white or black                            | RT30E5004-01-xxK*<br>4x PULSE<br>white or black                                    | RT42E5004-01-21K<br>Hand transmitter<br>4x PULSE                                    | RT43E5004-01-21K<br>Hand transmitter<br>4x PULSE                                    | RT32E5001-01-xxK*<br>1x UP/STOP/DOWN<br>white or black                              | RT32E5004-01-xxK*<br>4x UP/STOP/DOWN<br>white or black                              | RT34E5004-01-xxK*<br>2x UP/STOP/DOWN<br>2x ON/OFF                                   | RT34E5005-01-xxK*<br>5x ON/OFF<br>white or black                                    | RT34E5010-01-xxK*<br>10x PULSE<br>white or black                                    | RT26E5001-12-23K<br>Wristband transmitter<br>1x PULSE                               |

|   |   |   |  |   |   |   |   |   |   |   |   |
|---|---|---|--|---|---|---|---|---|---|---|---|
|  |  |  |  |  |  |  |  |  |  |  |  |
| RT27E5001-11-23K<br>Necklace transmitter<br>1x PULSE                              | RT28E5001-11-xxK*<br>Push button transmitter<br>1x PULSE                          | RTS13E5001-01-02K<br>Wall transmitter<br>1x UP/STOP/DOWN                          | RTS22E5002A12<br>Wall transmitter<br>1x ON/OFF, Format 55                          | RTS22E5001B02<br>Wall transmitter<br>1x AUS, Format 55                              | RTS22E5001A04-40K<br>Wall transmitter<br>1x CALL, Format 55                         | RTS22E5001A05<br>Wall transmitter<br>1x CALL, Format 55                             | RTS22E5001B01<br>Wall transmitter<br>1x QUIT, Format 55                             | RTS23E5004A12<br>Wall transmitter<br>2x ON/OFF, Format 55                           | RTS25E5001-01<br>Sensor wall switch<br>1x PULSE, Format 55                          | RTS25E5001-03<br>Sensor wall switch<br>1x CALL, Format 55                           | RTS07E5004-01-02K<br>Radio time switch<br>4x UP/STOP/DOWN                           |

**RECEIVERS**

|   |   |   |  |   |   |   |   |   |   |   |   |
|---|---|---|--|---|---|---|---|---|---|---|---|
|  |  |  |  |  |  |  |  |  |  |  |  |
| RTS03E5002C01<br>Built-in transmitter<br>Multifunction                            | RTS17E5001A01-K<br>Bell signal forwarding<br>1x PULSE                             | RTS39E5002D01-K<br>Flush-mounted transmitter<br>230V                              | RTS43E5002Axx-01K*<br>Surface-mounted transmitter<br>230V or 12-24V                | RCL03E5002B01<br>2x Changeover, 12-24V<br>also available with IP65                  | RCL07E5002A21-02K<br>Mini receiver<br>2-Channel, 12-24V                             | RCL07E5002B0x-02K*<br>Call receiver<br>internal/external prog.                      | RCJ31EN5001A01-K<br>1x Normally open, 230V<br>potential-loaded                      | RCJ32EN5001A01-K<br>1x Changeover, 230V<br>potential-free                           | RCJ33EN5001A01-K<br>1x Changeover, 12-24V<br>potential-free                         | RCJ34EN5002A01-K<br>2x Normally open, 230V<br>potential-loaded                      | RCJ35EN5001A01-K<br>1x Motor, 230V<br>potential-loaded                              |

|   |   |   |   |   |   |   |   |   |   |   |   |
|---|---|---|---|---|---|---|---|---|---|---|---|
|  |  |  |  |  |  |  |  |  |  |  |  |
| RCJ14E5001-01-23K<br>1x Dimming, 230V<br>Button input                               | RCJ18E5001A01-23K<br>1x Dimming, 12-48V<br>(LED-Strips)                             | RCJ15E5001-01-23K<br>1x Heating control 230V<br>ON/OFF or PWM                       | RCP14E5001-01-01K<br>1x Dimming, 230V<br>Local operation                            | RCP20EN5001A01-K<br>1x Normally open, 230V<br>TIMER                                   | RCP22E5001A01<br>1x Heating control, 230V<br>ON/OFF or PWM                            | RCP23EK5001A01-K<br>1x PULSE output,<br>24V, potential-free                           | RCP24E5001A01-K<br>Radio bell<br>12 melodies  | RCP25E5001A01-K<br>Pager<br>12 melodies   | RCU08EN5002A01-K<br>Surface-mounted receiver<br>2-Channel, pot.free, 230V             | RCA04E5001A01-29K<br>Access control<br>1x Changeover, 230V                            | RCH01E5005-01-29K<br>Heating circuit controller<br>5 outputs, 230V                    |

**SENSORS**

|   |   |   |  |   |   |   |   |   |   |   |   |
|---|---|---|--|---|---|---|---|---|---|---|---|
|  |  |  |  |  |  |  |  |  |  |  |  |
| RCR02EN5002A01-29K<br>2x Switch, 230V<br>potential-free                             | RCR02EN5004A01-29K<br>4x Switch, 230V<br>potential-free                             | RCR03EN5002A01-29K<br>2x Motor, 230V<br>potential-loaded                            | RCR03EN5004A01-29K<br>4x Motor, 230V<br>potential-free                               | RRP01E5023A01-K<br>MiniPager<br>Display, rechargeable                                 | RTS40E5001B01-K<br>Motion detector<br>AUTO  | RTS40E5001B02-K<br>Motion detector<br>I/O/AUTO  | SM01E5001A01-01K<br>Motion detector<br>Outdoor use, 230V                              | ST01E5001-01-02K<br>Temperature sensor<br>Heating                                     | ST02E5001-01-02K<br>Temperature sensor<br>Cooling                                     | STH01EN5001A01-02K<br>Temperature and<br>humidity sensor                              | RTS16E5001Xxx-xxK*<br>Window contact<br>ON/OFF, OFF/ON, STATUS                        |

**INTERFACES**

|   |   |   |  |   |   |   |   |   |   |   |   |
|---|---|---|--|---|---|---|---|---|---|---|---|
|  |  |  |  |  |  |  |  |  |  |  |  |
| RTS26E5001Xxx-xxK*<br>Window handle contact<br>ON/OFF, OFF/ON, STATUS               | SL01E5001-01-01K<br>Light sensor<br>for RTS07                                       | <a href="http://www.eldat.de">www.eldat.de</a>                                      | APC01ENS5031A01-21K<br>Control Center<br>Server                                      | RGK03ENS50A01-K<br>APPMODULE<br>KNX-IoT-Gateway                                       | RXJ03E5001B01-23K<br>Flush-mounted repeater<br>230V, cascadable                       | RXP05E50A01-K<br>Plug-in socket repeater<br>230V, cascadable                          | RCD22E5001A02<br>RS232 Interface<br>230V  | RGD03E5002A01-01K<br>DALI-Gateway, 200mA<br>configurable                              | RGD04E5001A01<br>DALI-Gateway, 24mA<br>2-button-dimming                               | APF03E5000A01-K<br>Easywave Fon Alarm<br>including RT26                               | <a href="http://www.eldat.de">www.eldat.de</a>  |

\* For variants of this product see catalog.